

Installation instructions

1. Unzip the .zip file to a temporary location on your PC .
2. Using Altair, copy everything in the "Copy to Topy" directory to the Topy.
3. Copy everything in "Copy to DigiGuide folder on PC" to the DigiGuide folder on PC (if you have DigiGuide installed) [A 30-day free trial can be obtained by clicking this link](#)

How to use this TAP

This TAP activates in normal mode

Keys

Press the WHITE key to display the timers list

When the timer list screen is displayed the keys functions as:

- LEFT : Select the previous day of the week
- RIGHT : Select the next day of the week
- LIST, or File List : Show all timers (remove the day of the week filter)
- UP : Move the cursor up one line
- DOWN : Move the cursor down one line
- << : Move the cursor up one page
- >> : Move the cursor down by a page
- OK : Edit the highlighted timer -> enter the timer edit screen
- RED : Create new timer
- Number key 0 ~ 9 : Jumps cursor to selected line
- RECALL : Select today as the day filter
- MENU : Display the menu for configuration and extended functions
- WHITE, or EXIT : Close the timer list window

[Sub-screens]

When the timer edit screen is displayed the keys functions as:

- UP : Move the cursor up one line
- DOWN : Move the cursor down one line
- LEFT : Decrement the currently highlighted selection
- RIGHT : Increment the currently highlighted selection
- OK : Calls up any menu associated with the currently highlighted selection
- TV/Radio : Swaps between TV and Radio channels (only when "channel" (name) is the currently highlighted selection)
- << : Load and edit the previous timer
- >> : Load and edit the next timer
- RECALL : Reload the original timer start date.
- Number key 0 ~ 9 : Quick key : Jumps cursor to selected line
- RECORD : Quick key : Save any changes and close the timer edit window
- EXIT : Quick key : Discard any changes and close the timer edit window

When the menu screen is displayed the keys functions as:

- UP : Move the cursor up one line
- DOWN : Move the cursor down one line
- OK : Select the currently highlighted timer
- EXIT : Close the menu window

[further sub-screens]

[Timer edit]

When the Channel selection screen is displayed the keys functions as:

- UP : Move the cursor up one square.
- DOWN : Move the cursor down one square.
- LEFT : Move the cursor left one square.
- RIGHT : Move the cursor right one square.
- TV/RADIO : Swaps between logos for TV and Radio.
- RECALL : Reload the timer's original channel.
- OK : Saves the currently highlighted channel and closed the Channel selection window
- EXIT : Discard any changes and close the Channel selection window (cancel)

When the Calendar screen is displayed the keys functions as:

- UP : Move the cursor back one week.
- DOWN : Move the cursor forward one week.
- LEFT : Move the cursor back one day.
- RIGHT : Move the cursor forward one day.
- RED : Move the calendar back one month.
- BLUE : Move the calendar forward one month.
- GREEN : Move the calendar back one year.
- YELLOW : Move the calendar forward one year.
- RECALL : Reload the timer's original start date.
- 0 : Select today's date.
- OK : Saves the currently highlighted date and closed the Calendar window.
- EXIT : Quick key : Discard any changes and closed the Calendar window. (cancel)

When the Keyboard screen is displayed the keys functions as:

- UP : Move the highlight up one square.
- DOWN : Move the highlight down one square.
- LEFT : Move the highlight left one square.
- RIGHT : Move the highlight right one square.
- << : Move the insert cursor one character to the right
- >> : Move the insert cursor one character to the left
- RECALL : Reload the original name
- OK : Inserts the highlighted letter at the current cursor position.
- WHITE : Quick key : Delete a character
- Number key 0 ~ 9 : Quick key : Direct insertion of a number
- PLAY : Quick key : Direct insertion of a space
- LIST : Quick key : Change the character set (shift)
- RECORD : Quick key : Save changes and exit (save)
- EXIT : Quick key : Discard changes and exit (cancel)

Extended command Menu

Configure : Change the way this TAP operates

Export timers : Save all your timers to the TimerList.txt file

Import timers : Loads timers from the TimerList.txt file

Import from DigiGuide : Run this after you have run the export command on your PC

Delete all timers : Deletes every timer on your Topy. Obviously that's not a wise thing to do!!!

Stop the TAP : Terminate and unload this TAP from your Topy's memory.

Credits : Shows who the development team are.

DigiGuide import usage instructions:

Within DigiGuide mark those programmes you want to record with the "Video" tag.

Run Export_Timers.bat

Within UkTimers (on the Topsy), press menu and then select "Import from DigiGuide"

Notes:

export.ini controls which categories are exported. The .ini file provided selects "Video" and "Watch" – that's because I got far too many repeat timers exported by including the favourites category – which I have repeat timers set for anyway.

The extract and copy routines require the user to specify the directories in the Export_Timers.bat file. Currently they are set for:

DigiGuide program location on PC = c:\program files\DigiGuide TV Guide

UkTimers destination folder on Topsy = \ProgramFiles\Auto Start\UK TAP Project

Obviously you'll need to change these if you use different directories.

I had to set a channel number for each listing on my DigiGuide. That may be something left over from when I altered the numbers to match my Pace DTVA. Take a look at the output file "TimerExport.txt". If the line starts with a large blank space, and then the channel name, then you'll need to set the channel numbers. Right click on each channel logo, and select "Change channel details"

[A 30-day free trial of DigiGuide can be obtained by clicking this link](#)